


## Documentatie tehnica Pulverizator RSE500



| Nr.crt | Denumire produs   | Product name     | Cod comanda   |
|--------|-------------------|------------------|---------------|
| 1      | Curea             | belt             | psrse500-1-1  |
| 2      | Alimentator       | charger          | psrse500-1-2  |
| 3      | Maner             | Handle           | psrse500-1-3  |
| 4      | Capac superior    | Top cover        | psrse500-1-4  |
| 5      | Sita              | filter screen    | psrse500-1-5  |
| 6      | Suport lance      | Lance holder     | psrse500-1-6  |
| 7      | Bazin             | tank             | psrse500-1-7  |
| 8      | Capac             | cap              | psrse500-1-8  |
| 9      | Buton on/off      | switch on/off    | psrse500-1-9  |
| 10     | Suport incarcare  | charger bottom   | psrse500-1-10 |
| 11     | Acumulator        | battery          | psrse500-1-11 |
| 12     | Pompa             | engine /pump     | psrse500-1-12 |
| 13     | Filtru            | filter           | psrse500-1-13 |
| 14     | Colier            | Clamp            | psrse500-1-14 |
| 15     | Conector          | connector        | psrse500-1-15 |
| 16     | Colier            | Clamp            | psrse500-1-16 |
| 17     | Colier            | Clamp            | psrse500-1-17 |
| 18     | Manson            | sleeve           | psrse500-1-18 |
| 19     | Suport            | bottom           | psrse500-1-19 |
| 20     | Capac             | cover            | psrse500-1-20 |
| 21     | Furtun            | hose             | psrse500-1-21 |
| 22     | Maner declansator | switch head      | psrse500-1-22 |
| 23     | Lance             | nozzle connector | psrse500-1-23 |
| 24     | Surub             | screw            | psrse500-1-24 |
| 25     | Surub             | screw            | psrse500-1-25 |
| 26     | Indicator         | indicator        | psrse500-1-26 |